

# IMPORTANT PLEASE READ FIRST!

## Eject Button on CD-RW

The MPC4000 uses a **SOFT EJECT FUNCTION** instead of the hardware eject button when there is a disk in the drive. If there is no disk in the drive, then the hardware button works, but not the software eject.

The soft Eject key can be found either:

A) in the LOAD or UTILITY pages:

- If the current selected drive is already the CD-RW drive, simply press F3 (EJECT).
- If the current selected drive is another drive (for instance the internal Hard drive):
  - 1) place the cursor on the "Disk:" field
  - 2) turn the data wheel to open the disk list and move the cursor over the CD-R/W drive
  - 3) press F3 (EJECT)

B) in the RECORD page

- 1) place the cursor on the "Input Source:" field
- 2) turn the data wheel to select INTERNAL (Analog or Digital)
- 3) press F3 (EJECT)