

# MPX8 Firmware Update Instructions, v1.1.01

## Release Notes

Firmware v1.1.01 implements the following changes:

- Allows MPX8 to use stereo samples
- Improves response of Data Dial.

## Instructions

**Warning:** During the following steps, do NOT remove the SD card or power MPX8 off. Doing so could damage your MPX8.

1. Place the **MPX8\_UPD.DAT** file on the root (main) directory of an SD card (formatted to a FAT16 or FAT32 file system).
2. Insert the SD card into MPX8's SD card slot.
3. On your MPX8, press and hold both **Select +** and **Volume +**, power MPX8 on, and then release the buttons.
4. When prompted, press **Volume +**.
5. When prompted again, press **Volume +** to confirm you want to update. The display will show **Erasing Firmware** and will show the firmware update's progress.
6. When the display shows **Complete**, power-cycle MPX8 (power it off then on again). After this, MPX8 is ready to use with its new firmware.

For additional help, visit  
**[akaipro.com/support](http://akaipro.com/support)**